# **IsatPhone**PRO

# network connection guide

## making a call:



- Stand outside in an open space with an unobstructed view of the sky
- Hold the phone in an upright position, looking at the screen
- Deploy antenna



- Searching satellite appears as the phone searches for a GPS fix and a connection to the Inmarsat network
- Successful connection is achieved when:
  - Ready for service is displayed
  - An audio signal is emitted
  - Inmarsat is displayed

This quick reference guide is intended to help you set up a network connection. Please contact your service provider for further information.



### troubleshooting:

#### no GPS fix 🜐




- The above icon will be displayed if a new GPS fix is required
- Find a location outside with an unobstructed view of the sky and ensure the antenna is deployed
- Hold the phone in an upright position, looking at the screen, and press **Search**
- The red icon will disappear once a new GPS fix is acquired
- If you do not get a fix, select Menu > GPS position to view the GPS satellite info graph. Change your position to maximise the GPS satellite signal strength bars on-screen
- When successful, the message **GPS fix acquired** will be displayed

#### inmarsat.com/isatphone

While the information in this Connection Guide has been prepared in good faith, no representation or warranty, express or implied, is made or given as to the adequacy, accuracy, reliability or completeness of such information. Immarsat Global Limited nor any group company or their respective officers, employees or agents shall have any responsibility or lability to any person resulting from the use of the information in this User Guide. Copyright @ Inmarsat Global Limited 2011. All rights reserved. INMARSAT is a registered trademark of the International Mobile Satellite Organisation; the Inmarsat LOGO is a registered trademark of Inmarsat (IP) Company Limited. Both trademarks are licensed to Inmarsat Global Limited. IsatPhone Pro CG February 2011.

#### no network



- If Limited service or pointing information is displayed, change location to an open space with an unobstructed view of the sky
- Deploy the antenna and hold the phone at a 45° angle to the horizon
- Press Search and keep still until Ready for service is displayed



- If search fails, an error message is displayed
- Turn right 90° keeping the phone at the same 45° angle, and press **Search**
- Repeat, if necessary, turning 90° each time until back in original position
- Anternatively try another location

